

Heritage Plastics

FULL TRUCKLOADS

The way to determine a full truckload is to assign a point value to each lift as follows:

A full truckload consists of 80 points or
40,000 lbs. whichever comes first

10-Foot Product

20 - Foot Product

| <u>Size</u> | <u>Point Value</u> | <u>Lift Quantity</u> | <u>Point Value</u> | <u>Lift Quantity</u> |
|-------------|--------------------|----------------------|--------------------|----------------------|
| 1/2 | 1 1/4 | 6000' | 2 1/2 | 12000' |
| 3/4 | 1 1/4 | 4400' | 2 1/2 | 8800' |
| 1 | 2 | 3600' | 4 | 7200' |
| 1 1/4 | 2 | 3300' | 4 | 6600' |
| 1 1/2 | 2 | 2250' | 4 | 4500' |
| 2 | 2 | 1400' | 4 | 2800' |
| 2 1/2 | 2 | 930' | 4 | 1860' |
| 3 | 2 1/2 | 880' | 5 | 1760' |
| 3 1/2 | 2 1/2 | 630' | 5 | 1260' |
| 4 | 2 1/2 | 570' | 5 | 1140' |
| 5 | 2 1/2 | 380' | 5 | 760' |
| 6 | 2 1/2 | 260' | 5 | 520' |

Telephone Duct—B—C—D

| | | | | |
|---|---|---|---|-------|
| 4 | - | - | 5 | 1260' |
|---|---|---|---|-------|

This formula may not work out exactly, depending on the mix of the load. For example, the weight limit of 40,000 pounds may be exceeded before the total quantity is reached, especially if the truck consists mainly of small diameter pipe.

An example of a full truckload would be 40 lifts of 2" X 10' product, equaling 80 points (56,000') or 20 lifts of 2" X 20' product equaling 80 points (56,000').